

### When engine is still warm

Without pulling the choke button, operate the starter to start. For easy starting, apply foot pressure lightly on to the accelerator pedal.

### When engine starting is difficult

1. When starter is continuously used for a length of time, the battery will be greatly impaired. Therefore take intervals in starting to relieve the battery of load.
2. If engine refuses to start, depress the accelerator pedal all way in and operate the starter. If accelerator pedal is repeatedly depressed, it will result in the suction of raw gas, making it further difficult to start.
3. If engine still refuses to start, check the engine to establish the cause of trouble.

### CAUTIONS TO BE OBSERVED BEFORE STARTING

1. If the oil pressure warning lamp is lighted with engine held idling, engine should be stopped immediately to examine cause of trouble. Failure to observe such precaution leads to serious engine trouble.
2. Until the engine warms up, raise the idling speed slightly to facilitate temperature increase. When driven while cold, engine life will be considerably shortened with increase in fuel consumption. Choke control knob should be pressed all way in when engine reaches normal operating temperature.
3. Refrain from racing the engine. When engine is cold, the moving parts are not sufficiently lubricated because of high viscosity in oil. Engine operation at high speeds under such condition accelerate wear of the parts.

### TRAVELLING

1. Even after the running-in period (initial 1,600km, or 1,000 miles of travel), the automobile should be operated according to the reference speeds figures given below to prevent over-revving the engine.

Model	1st gear	2nd gear	3rd gear	4th gear
PR20	Max. speed km/H (mile/H)	30 (20)	50 (30)	80 (50)
	Min. speed km/H (mile/H)	—	—	15 (10) 25 (15)
TR50	Max. speed km/H (mile/H)	40 (25)	70 (45)	110 (70) 160 (100)
	Min. speed km/H (mile/H)	—	—	25 (15) 35 (20)

\* : Final gear ratio, 4.100

2. Fuel consumption differs greatly according to manner in which the automobile is operated.
  - High speed driving increases fuel consumption.
  - Refrain from sudden acceleration and perform controlled speed driving.
  - Driving the automobile at speeds lower than the minimum speed limits with respect to individual gear will result in over-loading the engine and increase in fuel consumption.
3. Pay close attention to meters and warning lamp while driving.
4. Be sure to stop the car completely before shifting gear into reverse.

### HIGH SPEED OPERATION

#### (For model PR50 & PR91 especially)

1. Tire pressure should be increased by 0.5kg/cm<sup>2</sup> or 7psi before the automobile is subjected to continuous high-speed operation.
2. Oil pressure should also be carefully noted. It is normal at 3~4kg/cm<sup>2</sup> or 42~57 psi.
3. Engine speeds should be allowed to decrease as low as to 3500~4000 rpm before the gear is shifted down.

## PARKING

When leaving the car be sure always to turn-off the switch and apply the hand brake firmly. In case of hilly road, hold the gear control lever shifted into 1st gear or in reverse for additional safety.

## DRIVING IN WINTER SEASON

1. Cooling water freezing is liable to cause damages to cylinder body and head, therefore when stoping the car, drain the cooling water completely. The use of anti-freeze eliminates such troubles, but since there are anti-freeze solution with inferior quality sold on market, it is advisable to use recommended solution to prevent possible corrosion of the cooling system.
2. Because of frequent use of lighting system and heater, battery is more liable to discharge. Also, efficiency of the battery tends to decline with fall in ambient temperature. Therefore always keep the battery completely charged.
3. Operation of engine in over-cooled condition accelerates the parts wear. In case if the cooling water fails to reach normal temperature during operation, check the thermostat for failure. In extremely cold weather, prevent engine from over-cooling by using radiator cover (curtain). Suitable temperature 70°C~85°C (158°F~185°F).

## CHECKS AND SIMPLE ADJUSTMENTS PRIOR TO DRIVING

For safety of operation and driving comfort, it is recommended that the following check-ups be made regularly.

**Items with asterisk \*** should be checked prior to driving.


In order to lengthen the life of car and maintain the car in the best of conditions and to enjoy the ultimate in motoring satisfaction, periodical lubrication, check-ups and adjustment are essential.

Refering to lubrication chart, and checking and adjustment chart, perform work as indicated. It is recommended that lubrication, checking and adjustments be done at your nearest distributor's or dealer's service shop.

### Cooling water \*


Cooling water checks and replenishing are performed by removing the radiator cap.


When removing cap with engine in overheated condition, place cloth over the filler cap and turn it a half-turn and allow pressure to be fully released before completely removing it.



It is standard to change cooling water after **every 18,000 km (12,000 miles)** traveling.

To drain the cooling water, open the drain cocks on the lower part of the radiator and on the engine block.




**Fan belt tension ✪**

Check the belt tension prior to driving and adjust it if necessary.

Push the mid-section of fan belt between water pump and generator with thumb and see if it gives deflection of about 15 mm (0.6 in.).


For adjustment, loosen the generator bracket bolts and pivot the generator as required.

Faults occur if belt tension is either too loose or too tight.

**Engine oil ✪**


Before starting the engine, check oil level with dipstick.

Oil level is normal if it comes within the two notched marks. Oil changing should be done after the initial 1,000km (1,000 mile) of running-in period and thereafter it is standard to change every 3,000km (2,000 miles) travelling.


**Oil filter**

When changing engine oil (after every 3,000 km (2,000 miles)) drain oil also from drain plug (A).

After every 9,000 km (6,000 miles) travelling, replace oil filter element (B).

**Oil separator**

After every 18,000km (12,000 miles) interval, take out the separator and clean the internal part with gasoline or detergent oil.



## AIR CLEANER MAINTENANCE


- Every 2,000 miles remove filter element and clean by vibrating or blowing air from inside.
- Every 12,000 miles replace filter element with new one.
- When element is found damaged or stained with oil or grease replace immediately with new one.
- Under extremely dusty conditions, clean and replace more frequently.

### Carburettor

Maladjusted carburettor gives direct influence upon the engine performance. Hence, such check and adjustment of carburettor particularly those in the model PR 91 & PR 50 should be relied upon your closest distributor or dealer. Procedures for adjusting carburettor for model PR 20 are given below for your reference.

**Idle adjustment** is performed by screwing-in full the adjusting screw (A), then return  $1\frac{1}{4}\sim 1\frac{1}{2}$  turns and while manipulating the idling speed screw (B) set the engine revolution to about 550~600 rpm.


Next, while manipulating the adjusting screw (A), seek the spot at which the engine holds the fastest idle, and once again while manipulating the idling speed screw, set the engine revolution to 550~600 rpm.



for PR20

### Fuel filter


Cartridge type filter element is used to eliminate the need for servicing. Replace the element with the Isuzu Genuine filter element at every 20,000 km (12,000 mile) interval.



### Distributor

After every 3,000 km (2,000 miles) travelling, lubricate the rotor camshaft (A) and the arm shaft (B) by applying few drops of engine oil.


After every 3,000 km (2,000 miles) travelling, grease thinly the external surface of cam and at the same time check the gap (C) of contact point. **Adjusting value** is  $0.45\sim 0.55$  mm ( $0.018\sim 0.021$  in). Loosen lock screw and while moving the contact point, adjust the gap. After adjustment, be sure to tighten securely the lock screw. If point is contaminated, wipe it off with clean cloth soaked with gasoline.



### Sparkling plug

After every 3,000km (2,000 miles) travelling, clean and check and adjust if necessary.


**Adjusting value** is  $0.7\sim 0.8$  mm ( $0.027\sim 0.032$  in). Adjust the spark gap by bending ground electrode.



### Ignition timing

After every 3,000km (2,000miles) travelling, check the timing and make adjustment if necessary. The standard ignition timing is  $14^\circ$  before T.D.C. at 550-600rpm. However, it is necessary to have the Isuzu Distributor or dealer reset the ignition timing to  $8^\circ$  before T.D.C at 550-600 if regular grade gasoline is used. The micro-adjuster on the distributor is used to make micro adjustment on the ignition timing.

The ignition timing is correct if a sudden acceleration from 25km/h (16 miles/h) or so with the transmission in the top gear is accompanied by a slight engine knocking which gradually diminishes with increase in the engine speed.



To obtain micro-adjustment, proceed as follows:


If the engine knocking is excessive, turn loose the lock screw and turn the micro adjuster toward "R" and if the engine does not evidence knocking, turn the adjuster toward "A". After adjustment, securely tighten the lock screw.

### Steering ✪

Wheel play on the periphery is standard at 0~5mm (0~0.2 in).

Check whether looseness has developed in the steering system.

For safety precaution, check the steering wheel for smooth operation. If faults should occur refer the matter immediately to the nearest "Isuzu Service shop".




### Brake system ✪

#### Brake fluid level

Check after every 3,000 km (2,000 miles) of travel distance.

It is proper if brake fluid is up to the level of fluid reservoir. If insufficient, replenish with "Recommended Brake Fluid". If fluid falls considerably, be sure to check the cause and make necessary correction before starting to drive.



#### Inspect pedal play and stroke


Standard of play (free pedal travel) is about 35 mm (1.4 in). When fully depressed, if gap between pedal and floor board is less than 60 mm (2.4 in), adjustment is necessary.

### Brake adjustments

Lower the hand brake lever, remove wheel cap and insert screwdriver into the adjusting hole for adjustment.

For front wheels, return the adjuster 6~8 notches from the fully dragged position. For rear wheels, turn the adjusting cam all the way to the right until wheels are dragged and return the adjuster 2 notches back.


Model PR 91 & PR 50 is equipped with self-adjusting front disk brakes which require no adjustment.



#### Hand brake

Hand brake lever travel allowance is standard at 4~5 notches.


If rear brake is adjusted, the brake lever travel is automatically adjusted, but when the hand brake's lever travel is excessive, adjust the cable length until the slack of hand brake cable is eliminated.



Note: Faulty adjustments of brake system are liable to cause major accidents, therefore, if service brakes or parking brakes fail to function properly, or trouble such as over-heating is noted, contact the Isuzu Service Station immediately to get proper maintenance attention.

### Windshield washer tank

Replenish with tap water or neutralized soap water.



## Tire air pressure \*


Check tire pressure **every day**. Tire pressure influences greatly riding comfort and tire life, therefore be sure to check the pressure with gauge and keep the tires properly inflated.

### Standard air pressure

Tire size	Front, kg/cm <sup>2</sup> (psi)	Rear, kg/cm <sup>2</sup> (psi)
For PR 20 5.60-13-4PR	1.40 (20)	1.40 (20)
*6.00-13-4PR		
*(5.60-14-4PR)	1.55 (22)	1.70 (24)
For PR91 & PR50 5.60-13-4PR	1.55 (22)	1.70 (24)

\* optional

It is essential that pressure be raised by 0.5kg/cm<sup>2</sup> or by 7PSI when the model PR 91 & PR 50 is subjected to continuous high speed cruising.




## Tire changing

To change tire due to puncture, perform according to the following. Bring the car where the ground is hard and flat. Then take out the spare tire, jack, tools from the trunk.

When removing front tire, apply hand brake fully and when removing rear tire, block left and right front tires.




Remove the bolt of spare tire with wheel brace




Take out the spare tire


Wheel nuts can be securely tightened by applying strong force to push up or bring down the wheel brace by hand. Tighten the nuts evenly.



When fitting tires, be sure to match the brake adjusting hole in the disc wheel with that in the brake drum.




Fit the jack into one of the round socket located below the individual door. Then turn the handle clockwise to raise the jack.



## Rotation of tire

Subsequent tire interchanging should be made including one reserved for spare. Absence of valve cap permits admission of dust into the tire during air filling.

Check the tire tread very carefully. Upon detection of any abnormal wear, contact Isuzu Service Station immediately for establishment of cause and proper means of rectification.



It is recommended that tires should be interchanged after every 9000 km (6000 miles) of road service.

## Electrical system

### Meter and switch ✪

Does each meter and switch function properly?

Inspection and adjustments of meters and switches, should be carried out by the Isuzu Service Station with their precise instrumentation.

### Battery


Every week, check electrolyte level and leakage of battery. When replenishing electrolyte, only distilled water should be used. In summertime, quantity of electrolyte is liable to become insufficient, therefore check-up should be made appropriately.

After every 3,000 km (2,000 miles), of travelling, check terminal for looseness, and electrolyte specific gravity. Do not forget to apply grease to terminals after they are cleaned.

### Fuse box

Fuse box is located on the right side of dash panel inside the engine room. 4 fuses are used and 2 spare fuses are inserted.

When fuse burns out, check the cause and after repairing, fit spare fuse of the specified amperage capacity.




## Bulb replacement

### Head lamp



Remove the 4 screws to remove the rim.



Turn loose set screws and turn the lens frame counter-clockwise so that the frame releases, giving access to the light bulb.

Since head lamp is sealed beam type, replace lens and reflectors as an unit.


Outer lamp is 12V-50W/37.5W

Note: dipping beam

RHD—left dip 50W,

LHD—right dip 50W.


Inner lamp is 12V-37.5W




### Side Flasher (sub) lamp

From the inner side of fender, pull out the dust cover and socket in one unit and then remove.



The bulb 12V-3.4W.



**Parking and flasher lamp (PR 20 & PR 50)**

When the 4 screws of lens are removed, lens is removable. By pushing in slightly and turning counter-clockwise, the bulb can be removed.

The bulb is 12V-7W/23W.

**Parking and flasher lamp (PR 91)**

Take out a screw from the lens frame and remove the frame.


Remove three snap springs from the frame. For removing the bulb, push it in lightly with fingers and turn it counter-clockwise.

The parking and flasher lamp has two filaments incorporated in the same bulb, the capacity of which are 21 W and 6W respectively.

**Stop/flasher lamp, tail and reverse lamp.**


The light bulb is accessible with the luggage compartment lid opened.

Turn the socket counter-clockwise so that light bulb can be removed together with the socket. The light bulb can be taken out from the socket by turning the bulb counter-clockwise.

**License Plate lamp**


By removing the rubber gasket in the rear side of lens, the bulb can be removed.

The bulb is 12V-6 W.

**Room lamp**


When lamp cover is removed, the bulb is removable.

The bulb is 12V-6 W.



# EQUIPPED TOOLS

## Details of common tools



- 1. Tool bag
- 2. Open ends spanner set
- 3. Screw driver, small
- 4. Screw driver, large
- 5. Screw driver,  $\oplus$  head
- 6. Plier
- 7. Adjustable wrench
- 8. Wheel cap remover
- 9. Wheel skid
- 10. Spark plug wrench
- 11. Tire gauge
- 12. Wheel brace
- 13. Jack

# LUBRICATION

## Basic selectivity of lubricants

Lubrication Point	Lubricants	
Engine	Engine oil, API service MS class	
	Outside temperature	SAE groups
	Above 27°C (80°F)	SAE 40
	0°C~32°C (32°F~90°F)	SAE 30
	-12°C~16°C (10°F~60°F)	SAE 20W or 20
	Above -12°C (10°F)	SAE 20W-40
	Below 32°C (90°F)	SAE 10W-30
	Below 7°C (20°F)	SAE 10W
Transmission	Below -12°C (10°F)	SAE 5W-20
	All seasons	
Differential gear box	Engine oil or Multi-purpose gear lubricant	
	Outside temperature	SAE groups
	Above 4°C (40°F)	SAE 40
	7°C~21°C (20°F~70°F)	SAE 30
	Below 16°C (60°F)	SAE 10W-30 or 20W-20
Steering gear box	Below 0°C (32°F)	SAE 5W-20
	Multi-purpose gear lubricant	
	Outside temperature	SAE groups
Wheel hub bearing	Above 10°C (50°F)	SAE 140
	12°C~27°C (10°F~80°F)	SAE 90
	Below 10°C (50°F)	SAE 80
Chassis	Chassis lubricants or Multipurpose lubricant	
	NLGI No.1 or No.3	
Front suspension Steering track rod joint bolt	Wheel bearing grease or Multi-purpose lubricant	
	NLGI No.2 or No.3	
Steering track rod joint bolt	Molybdenum disulfide grease	
	NLGI No.1 or No.2	

## LUBRICATION

---

Chassis	Molybdenum disulfide grease
Propeller shaft universal joint	NDGI No.1 or No.2
Rear swing axle universal joint	
Water pump bearing unit & clutch release bearing unit	
Brake & clutch (LHD) Master cylinder tank	Hydraulic Brake Fluid Heavy Duty type SAE 70R1 or SAE 70R3

## Chassis-lubrication chart

Differential Gear Box;—  
API-MP class

Hypoid gear oil

CHANGE EVERY 18,000km (12,000mile)

Capacity.....0.7ℓ (0.19 US gal)

Universal Joints;—

\*Molybdenum-Disulfide Grease

NLGI #2 or #1

LUBRICATE EVERY 18,000km (12,000mile)

Capacity.....16.5 gr (0.58 oz)

Brake Master Cylinder Tank;— &

Clutch (LHD) Master Cylinder Tank;— &

SAE70R1 or 3 Brake Fluid


SUPPLY EVERY 3,000km (2,000mile)

Capacity.....0.175ℓ (0.046 US gal)

<sup>a</sup>Transmission;— Same as Engine oil  
Gear box (SAE #30).....2.0ℓ (0.53 US gal)  
CHANGE EVERY 18,000km (12,000mile)

<sup>b</sup>Engine; Oil pan

API-MS class } ..... Capacity  
Engine oil } ..... 3ℓ (0.8 US gal)  
CHANGE EVERY 3,000km (2,000mile)



Rear Hub Bearings;—  
Wheel Brg. Grease,  
Multi-purpose type NLGI #2, #1  
CHANGE EVERY 18,000km (12,000mile)  
Capacity.....54 gr. (1.89 oz)

Hand Brake Cable;—  
Graphite Grease NLGI #2, #1  
LUBRICATE EVERY 9,000km (6,000mile)  
Capacity 10 gr. (0.35 oz)

Front Hub Bearings;—  
Wheel Brg. Grease,  
Multi-purpose type NLGI #2, #1  
CHANGE EVERY 18,000km (12,000mile)  
Capacity.....60 gr. (2.10 oz)

Joint Balls;—  
Suspension & Steering Track Rod, etc.  
\*Molybdenum-Disulfide Grease  
NLGI #2 or #1  
LUBRICATE EVERY 18,000km (12,000mile)  
Capacity.....64 gr. (2.26 oz)  
70 gr. (2.47 oz)

### Recommended Lubricants and Coolants


Lubricant & coolant	Product	Brand name
Engine oil	Showa-Oil K. K.	High Bellpa Engine Oil
Engine	"	Golden Parrot
Transmission	BP	BP Visco-Static Long Life
	"	BP Energol Visco-Static
	"	BP Energol HD Motor Oil
Caltex		Caltex Five Star Motor Oil
	"	Caltex RPM DELO Multi-Service oil
Union		Super-Royal Triton Motor Oil
	"	Royal Triton
Esso		Esso Extra Motor Oil
	"	Uniflo
	"	Esso Motor Oil
Shell		Shell X-100 Multigrade
	"	Shell X-100 Motor Oil
	"	Shell Super Motor Oil
Mobil		Mobiloil Special
	"	Mobiloil
Gear Lubricant	Showa-Oil K.K.	Bellpa Gear Oil
Transmission	BP	BP Energol Gear oil EP
Differential gear	Caltex	Caltex Universal Thuban
	"	Caltex Multipurpose Thuban EP
Union		Red Line MP Gear Lubricant
Esso		Esso Gear Oil GP
	"	Esso Gear Oil GX
Shell		Shell Spirax EP
	"	Shell Spirax Heavy Duty
Mobil		Mobilube GX
	"	Mobilube EP
	"	Mobilube HD
	"	Mobilube 46
Steering gear	Showa-Oil K.K.	Bellpa chassis grease
	"	Bellpa L grease NLGI No.2
BP		BP Energearse C2 or L2
Caltex		Caltex Marfak Multi-purpose 2

Steering gear	Caltex Union Esso " Shell Mobil	Caltex Marfak All Purpose Unoba A-1 or A2 Esso Multipurpose Grease Esso Chassis Grease L, H or XX Shell Retinax A or CD Mobilube GX, EP, HD, or 46
Wheel hub bearing	Showa Oil K.K. BP Caltex " " Union Esso " Shell " Mobil	Bellpa L grease BP Energearse L2 or N2 Caltex Marfak Multi-purpose 2 Caltex Marfak All Purpose Caltex Marfak Heavy Duty 2 or 3 Unoba 2 or 3 Esso Multi-purpose Grease Esso Chassis Grease L, H or XX Shell Spirax EP Shell Spirax Heavy Duty Mobilgrease MP or No.2
Chassis	Kyodo-Yushi K.K. -Nippon BP Caltex " " Union Esso " " Shell Mobil	ONE-LUBER No.1 or No.2 BP Energearse L2, C2, or Ao Caltex Marfak Multi-purpose 2 Caltex Marfak All Purpose Caltex Molytex 2 Unoba A-1 or A-2 Unoba 1 or 2 Esso Multi-purpose Grease Esso Chassis Grease L, H or XX Beacon Q2 Shell Retinax A, CD or AM Mobilgrease Special
Water pump brg. unit & clutch release brg. unit	Nippon Koyu K.K. -Nippon Showa-oil K.K. -Nippon BP Caltex " " Union "	Nippeco MP-1 grease Bellpa Chassis grease BP Energearse L2 Caltex Marfak Multi-purpose 2 Caltex Marfak All Purpose Caltex Water Pump Grease Unoba 2 or 3 Unoba A-2


Water pump brg. unit & clutch release brg. unit	Esso " Shell Mobil	Esso Multi-purpose Beacon EPI Shell Retinax A Mobilgrease MP
Brake & Clutch (LHD) fluid	Fujikura-Kasei K.K. -Nippon BP Caltex Esso Shell Mobil	ISUZU Genuine Brake Fluid HD or Super HG (Cold district) BP Brake Fluid Caltex Heavy Duty Brake Fluid Esso Brake Fluid HD 400 Shell Donax B Mobil Hydraulic Brake Fluid
Coolant		ISUZU Long Life Coolant

## BODY LUBRICATION CHART


ENGINE HOOD INSERT ROD




WIPER LINK




DOOR REGULATOR




DOOR HINGE





DOOR LOCK



ENGINE HOOD CATCH



ENGINE HOOD HINGE



LUBRICATE EVERY 3,000km (2,000 mile) TRAVELED




GREASE




ENGINE OIL

TRUNK LOCK



TRUNK HINGE



# WIRING DIAGRAM

## Description of wiring diagram

In the wiring diagram, alphabetical symbols are used for identification purpose. BW represents the initials of black and white, which in turn indicates the cord in black background with white traces.

Symbol	B	W	R	G	Y	L	O	G R
Color	Black	White	Red	Green	Yellow	Blue	Orange	—
								—
								—

— Color of trace (red)  
 — Cable background color (green)

Lighting switch connections	Key position	Cable color	R	G R/R G	G/G	R W
		Off	○	—	—	—
	1 Step	○	○	○	—	—
	2 Step	○	○	—	○	—


Starter switch connections	Key position	Cable color	B	L	B Y	B W
		Off	○	—	—	—
	# 3 (Left)	○	○	—	—	—
	# 1 (Right)	○	○	○	—	—
	# 2 (Right)	○	—	○	○	—

Flasher & dimmer switch connections	Lever	Cable color	G L	G W	G B	R Y	R W	R
		Right	○	○	—	—	—	—
	Left	—	○	○	—	—	—	—
	Main beam	—	—	—	—	○	○	—
	Sub beam	—	—	—	—	—	○	○


◊ : Stop lamp circuit

Wiper switch connections 2 - Speed	Key position	Cable color	B	L B	L W	L Y
		Off	○	—	○	—
	Low	○	○	○	—	—
	High	○	○	—	—	○

## **PR50 & PR91 WIRING DIAGRAM**




## **PR20 WIRING DIAGRAM**



# TROUBLE SHOOTING AND ITS TREATMENT

<b>Engine does not start</b>	Starter does not revolve	Battery discharged Imperfect connections Starter or switch troubles
	Starter turns over but no fuel in the carburettor	
<b>Fuel (petrol) in carburettor</b>	Spark plug—Sparks are weak	Variance ignition timing Faulty coil & condenser Burnt damage of point surface Faulty contact of point Short-circuits of breaker arm, rotor & dist. cap, etc.
	Spark plug failure	
	Sparks originate at tip of cord after removed from tip of plug	
<b>Too rich gas mixture—Over choking</b>		Faulty spark plugs Faulty coil & condenser Burnt damage of point Short-circuits of breaker arm & rotor, etc.

<b>Poor conditions of engine</b>	<b>Powerless</b>	Improper tappet adjustment		<b>Engine suddenly stops while driving</b>	Empty fuel (petrol) tank
		Valve spring fatigue			Unarrival of gasoline—Check fuel systems
		Bent valve			Fuel present in carburettor
		Clogged silencer			Clogged jet or pipe
		Retarded ignition timing			Overflows      {Sunken or stucked float Engine overheating}
	<b>Misfire</b>	Improper carburettor adjustment		<b>Troubles of electrical system</b>	Sparks at tip of cord after removing from tip of plug      }—Damaged spark plug
		Sparkings are weak			Loosened wiring
		Improper gas mixture			Faulty coil & condenser
		Poor quality gasoline (petrol)			Faulty contact point
		Clutch slips			Shorts in between
	<b>Over-heat</b>	Brake drags		<b>Suddenly stop following unusual noise</b>	Suddenly stop following }—Mechanical troubles
		Faulty carburettor			Unnecessary high revolution of engine
		Sticky valves			Improper adjustment of carburettor
		Dirty spark plugs			Faulty ignition timing
		Faulty contact points			Poor return of choke
<b>Fuel consumption is unusual</b>	<b>Irregular sparks</b>	Intermittent short-circuits		<b>Fuel consumption is unusual</b>	Poor quality gasoline (petrol)
		Too rich gas mixture			Slipping clutch driven plate
		Gasoline unbrought enough to carburettor			Brake drags
		Water in gasoline			Insufficient tire pressure
		Clogged jet of carburettor			Frequent operation in low gear
	<b>Braking effect becomes poor</b>	Insufficient cooling water amount		<b>Braking effect becomes poor</b>	Buoyant feeling when brake pedal is depressed }—Air in brake system—Air bleed
		Improper ignition timing			Only slight distance to floor when brake pedal is depressed      }Worn lining—Adjust brake
		Loosened or slipping fan belt			Insufficient }Check leaks & replenish brake fluid } brake fluid
		Faulty thermostat			Water penetrates into brake drum
		Clogged radiator			Slipping of brake linings, excessively worn lining
	<b>Insufficient or faulty lube oil</b>	Insufficient or faulty lube oil			



Gear does not mesh	Clutch does not engage
Unsmooth operation of gear (shift) control lever	Faulty adjustment of selector link
Gear is unreleased	Faulty adjustment of shifter link
	Stucked bush of control shaft
	Defective the transmission
	Clutch does not engage
	Faulty adjustment of selector link
	Faulty adjustment of shifter link
	Stucked bush of control shaft
	Defective the transmission

# PERIODIC CHECKS AND LUBRICATION

## TABLE OF BELLETT

- ※ Initial service only
- 3% Mo-No<sub>2</sub> Grease
- △ Ordinary Grease
- ◎ Every 20,000km (12,000mile)

Where to inspect	Inspection periods	Where to inspect					
		Inspection prior to driving	1,000 km (1,000 mile)	Every 3,000 km (2,000 mile)	Every 9,000 km (6,000 mile)	Every 18,000 km (12,000 mile)	Every 36,000 km (24,000 mile)
Radiator and hose joints and inspect water leaks and water level		○					
Inspect fan belt tension and condition		○	※				
Change cooling water (◎: In case of Long Life coolant)					○	◎	
Check engine oil amount and replenish		○					
Change engine oil			※	○			
Drain from engine oil filter			※	○			
Replace engine oil filter element					○		
Clean oil separator						○	
Replace air cleaner element						○	
Check leaks of fuel system		○	※	○			
Check for oil leaks from joints of lubrication system		○	※	○			
Air breather washing				○			
Replace fuel filter element						◎	
Check functions of fuel pump						○	
Further tightening of head bolts and manifold bolts			※		○		
Further tightening of engine mounting			※		○		
Check and adjust control link and wire				○			
Lubricate engine control link and wire				○			
Oil pan & strainer cleaning						○	
Drain from fuel tank drain plug						○	
Fuel tank cleaning						○	

Where to inspect	Inspection periods	Inspection prior to driving	1,000 km (1,000 mile)	Every 3,000 km (2,000 mile)	Every 9,000 km (6,000 mile)	Every 18,000 km (12,000 mile)	Every 36,000 km (24,000 mile)
			1,000 km (1,000 mile)	Every 3,000 km (2,000 mile)	Every 9,000 km (6,000 mile)	Every 18,000 km (12,000 mile)	Every 36,000 km (24,000 mile)
Check valve gaps (tappet clearance)				※		○	
Check intake air line				※	○		
Check & further tightening of exhaust manifold			※	○			
Idling adjustment (low & acceleration)					○		
Whether exhaust color is proper (check)			○		○		
Check fitting conditions of pedal						○	
Check clutch functions (LHD oil control)				※	○		
Check play and allowance of pedal			※	○			
Supply oil to pedal shaft link					○		
Check connection of control link						○	
Check operational conditions of controls				※		○	
Check oil leaks of gear box					○		
Check gear oil and replenish					○		
Change gear oil			※			○	
Supply oil to control links					○		
Check connection tightening of propeller shaft					※		
Check universal joints of prop. shaft & R-axle						○	
Grease universal joints			△		●		
Check vibration of propeller shaft						○	
Check spline						○	
Check foot brake effectiveness condition		○	※	○			
Check pedal play, depressing allowance, gap with floor board and air mixture		○	※	○			
Check fitting conditions of pedal and master cylinder						○	
Check the functions of master cylinder and wheel cylinder						○	
Check for pipe and hose damages, twists and contacts with other portion						○	
Check for brake oil leaks from the brake system						○	

Inspection periods		Inspection prior to driving	1,000 km (1,000 mile)	Every 3,000 km (2,000 mile)	Every 9,000 km (6,000 mile)	Every 18,000 km (12,000 mile)	Every 36,000 km (24,000 mile)
Where to inspect							
Brake	Check brake lining and brake drum (clearance), wears and also the contact			○	○		
	Supply oil to pedal shaft and push rod			○			
	Check brake oil amount			○			
Hand brake	Check hand brake effectiveness and pulling allowance (Damage to wearing section of ratchet)	○	※	○			
	Check joints of hand brake links and contacts with other parts			○		○	
	Grease hand brake links and cable					○	
	Check toe-in (Side slip testing)			○			
	F-rock to rock check & adjustment					○	
Steering	Play, looseness and wear of wheels	○		○			
	Operation conditions (swing, pulling and heaviness)	○		○			
	Check fixing conditions and damages of flexible coupling and track rod				○		
	Check wears of knuckle joints and damages				○		
	Check fitting conditions of steering rack pinion housing		※			○	
Axle · Suspension	Check wheel alignment				○		
	Lubricate steering rack pinion case				○		
	Grease joint ball connections		△				
	Grease link end portion		△		●		
	Check joint ball, rod & arms connections		※	○		●	
	Check rear axle shaft connected	※		○			
	Grease rear axle shaft & univ. joint		△		●		
	Looseness of front hub bearing		※	○			
	Check wheel bearings				○		
	Grease front hub				○		
	Grease rear hub				○		
	Check differential oil leaks		○				

Inspection periods		Inspection prior to driving	1,000 km (1,000 mile)	Every 3,000 km (2,000 mile)	Every 9,000 km (6,000 mile)	Every 18,000 km (12,000 mile)	Every 36,000 km (24,000 mile)
Where to inspect							
Brake	Check differential gear oil and replenish					○	
	Change differential gear oil				※		○
Hand brake	Check fitting conditions of shock absorbers & stabilizer					○	
	Check spring damages looseness fitting bracket	○		※		○	○
	Looseness and damage of fitting portion			※		○	
	Further tightening of wheel pin nut			※	○		
Steering	Changing tire position					○	
	Check tire pressure and unusual wear (Spare inclusive)	○		※			
	Change fitting positions of tire					○	
	Check disk wheel damages					○	
	Check door lock and opening, closing conditions of door			※	○		
	Lubricate door hinge, door lock, trunk hinge, trunk lock, bonnet hinge, bonnet catch, etc.			※	○		
	Check battery liquid amount	○				○	
	Check battery liquid gravity					○	
	Check battery fitting conditions, check conditions of battery terminals		※	○			
	Check charging conditions of generator				○		
	Check conditions of starter pinion					○	
	Clean starter commutator and check brush wears					○	
	Clean AC generator, check brush wears and lubricate (check functions)					○	
	Lubricate starter F-bearing						○
	Check functional operations of security assisting devices (Light, meter, wiper horn, flasher, each switches)	○			○		
Body	Check supports for piping, wirings and links and contact with other connections				○		
Wheel · Tire							
Axle · Suspension							
Electrical system							
Others							

Where to inspect Engine for gasoline-car	Inspection periods	Inspection prior to driving	1,000 km (1,000 mile)	Every 3,000 km (2,000 mile)	Every 9,000 km (6,000 mile)	Every 18,000 km (12,000 mile)	Every 36,000 km (24,000 mile)
Starting condition & noise		○	※	○			
Grease distributor cam				○			
Lubricate distributor shaft & arm shaft				○			
Clearance between contact point & arm				○			
Dirtiness & clearance of spark plugs				○			
Inspect function of vacuum & centrifugal advancers				○			
Inspect ignition timing				○			
Clean & inspect carburettor					○		
Measuring compression pressure						○	

Digitized by Aotearoa Archives Trust <http://nzarchives.com>

## HD-1306

You are requested to order this manual by using the manual number that is shown here.

Issued by

**ISUZU MOTORS LIMITED**

EXPORT TECHNICAL DEPT.

22-10 Minami-oi 6-chome, Shinagawa-ku, Tokyo, Japan

Cable Address "ISUZU TOKYO"

Telex: 0246-6219 ISUZU EXPORT TOK

Tel. Tokyo 762-1111